CABINET PARTS

WINE CELLAR

For Models: KUWA244PWH00, KUWA244PBL00, KUWA244PBS00, KUWA244PSS00
(White) (Black) (Black/Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KUWA244PWH00, KUWA244PBL00, KUWA244PBS00, KUWA244PSS00
(White) (Black) (Black/Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2300247	Use & Care Guide
	4344691	Wiring Diagram
2		Grille
	4344669	White
	4344670	Black
3	4344686	Shelf, Wine (5)
4	4344688	Condenser
5	4344607	Switch, Door
6	4344690	Thermostat
7		Knob, Thermostat
	4344671	White
	4344672	Black
8	4344602	Light Bulb
9	4344664	Cover, Hole
10	4344611	Drain Cup
11	4344655	Drain Pan
12	4344613	Drain Trough
13		Hinge, Top
	4344682	White
	4344693	Black
	4344697	Stainless
14		Hinge, Bottom
	4344683	White
	4344694	Black
	4344698	Stainless
15		Gasket, Door
	4344685	White
	4344696	Black
	4344700	Grey
16		Handle, Door
	8524416	White
	8524418	Black
	8524415	Stainless
17	4344621	Compressor (Includes Items 22, 25 & 32)
18		Cabinet (Not a Servicable Part)
19		Door Assembly
	4344684	White
	4344695	Black
	4344699	Stainless
20	4344625	Switch, Light
21	4344678	Socket, Light
22	4344687	Overload
23	4344662	Panel, Rear
24	4344667	Cover, Light
25	4344630	Drier
26	4344631	Fan Motor
27	4344632	Blade, Fan Motor
28	4344689	Power Cord
29	4344679	Evaporator
30	4344635	Foot, Leveling (4)
31	4344663	Screw
32	4344638	Relay
33	4344692	Wine Display Rack
34		Nameplate
	2209118W	White
	2217214B	Black
35	4344680	Closer, Door (Upper)
36	4344681	Closer, Door (Lower)
37	4344660	Clip
38		Plug, Door
	4344701	White Cabinet
	4344702	Black Cabinet
	4344703	Stainless Cabinet (Screw)
39	4344709	Bracket, Door Switch
40		Plate, Pivot
	4344919	White
	4344733	Black
41	4344710	Screw

REFRIGERANT CHARGE

4.0 oz.
(R−134A)